

1. UNDERGROUND UTILITY LOCATIONS ARE PLOTTED BASED ON THE BEST AVAILABLE INFORMATION. LOCATIONS SHOULD BE VERIFIED BY THE CONTRACTOR BEFORE WORK.

2. SEE PLANS DRAWING NO. 1 FOR PLAN NOTES AND GENERAL NOTES.

3. VERIZON UNDERGROUND TELEPHONE (STA. 396+50 STA. 405+50 RT)

PORTLAND CEMENT	393+00 -	394+05 RT
CONCRETE SIDEWALK - 5"	394+54 -	396+83 RT
	397+00 -	399+00 RT
	393+00 -	394+05 LT
	394+54 -	395+91 LT
	396+41 -	399+00 LT

CONSTRUCT DRIVE	SCALE IN FEET
394+29 RT - 35'	12.5
396+16 LT - 36'	16
396+96 RT - 12'	9.6

KURT V. REICHEL & LAURA M. REICHEL TRUSTS OF THE KURT V. REICHEL REVOCABLE TRUST

